

APPLICATION FOR OSHPD PREAPPROVAL

OFFICE OF STATEWIDE HEALTH PLANNING AND DEVELOPMENT **FACILITIES DEVELOPMENT DIVISION**

OFFICE USE ONLY

OF MANUFACTURER'S CERTIFICATION (OPM) APPLICATION #: OPM-0341-13
OSHPD Preapproval of Manufacturer's Certification (OPM)
Type: ☐ New ☐ Renewal ☐ Update to Pre-CBC 2013 OPA Number:
Manufacturer Information
Manufacturer: ADVANCED STERILIZATION PRODUCTS
Manufacturer's Technical Representative: Michael Gallucci
Mailing Address: 33 Technology Drive, Irvine, CA. 92618
Telephone: On File Email: On File
Product Information OS DDd
Product Name: Water Filtration System
Product Type: Other Mechanical and Electrical Components
Product Model Number: N/A BY: William Staehlin
General Description: Filters water-feed to sterilizers
DATE: 05/30/2017
Applicant Information
Applicant Company Name: EASE Co.
Contact Person: Jonathan Roberson, S.E.
Mailing Address: 5877 Pine Ave. Suite 210, Chino Hills, CA. 91709
Telephone: _(909) 606-7622
I hereby agree to reimburse the Office of Statewide Health Planning and Development review fees in accordance with the California Administrative Code, 2016.
Signature of Applicant: Date: 4/18/16
Title: Principal Engineer Company Name: EASE Co.

"Access to Safe, Quality Healthcare Environments that Meet California's Diverse and Dynamic Needs"







OFFICE OF STATEWIDE HEALTH PLANNING AND DEVELOPMENT **FACILITIES DEVELOPMENT DIVISION**

Registered Design Professional Preparing Engineering Recommendations
Company Name: EASE Co.
Name: Jonathan Roberson, S.E. California License Number: S4197
Mailing Address: _ 5877 Pine Ave. Suite 210, Chino Hills, CA. 91709
Telephone: 909-606-7622 Email: <u>J.Roberson@EASECo.com</u>
OSHPD Special Seismic Certification Preapproval (OSP)
 □ Special Seismic Certification is preapproved under OSP- (Separate application for OSP is required) □ Special Seismic Certification is not preapproved
Certification Method(s)
☐ Testing in accordance with: ☐ ICC-ES AC156 ☐ FM 1950-16 ☐ Other* (Please Specify):
OPM-0341-13
*Use of criteria other than those adopted by the California Building Standards Code, 2016 (CBSC 2016) for component supports and attachments are not permitted. For distribution system, interior partition wall, and suspended ceiling seismic bracings, test criteria other than those adopted in the CBSC 2016 may be used when approved by OSHPD prior to testing. Analysis DATE: 05/30/2017 Experience Data
Combination of Testing, Analysis, and/or Experience Data (Please Specify):
List of Attachments Supporting the Manufacturer's Certification
 ☐ Test Report ☐ Drawings ☐ Calculations ☐ Manufacturer's Catalog ☐ Other(s) (Please Specify):
OFFICE USE ONLY - OSHPD APPROVAL VALID FOR CBC 2016 & ALL PRE-2016 CODE BASED PROJECTS
Signature: Date: D5-30-2017
Print Name: William Staehlin
Title: SSE
Condition of Approval (if applicable):

"Access to Safe, Quality Healthcare Environments that Meet California's Diverse and Dynamic Needs"





Page 2 of 2



EQUIPMENT ANCHORAGE & SEISMIC ENGINEERING

5877 Pine Ave, Ste. 210 Chino Hills, CA. 91709 Phn: (909) 606-7622

Office of Statewide Health Planning and Development

PREAPPROVAL OF MANUFACTURER'S CERTIFICATION OPM-0341-13

THIS PREAPPROVAL CONFORMS TO THE 2016 CALIFORNIA BUILDING CODE

MANUFACTURER:

EQUIPMENT NAME:

ADVANCED STERILIZATION PRODUCTS


WALL MOUNTED WATER FILTRATION SYSTEM

Sheet: 1 of 5

Date: 5/3/17

GENERAL NOTES

- 1. THIS OSHPD PREAPPROVAL OF MANUFACTURER'S CERTIFICATION (OPM) IS BASED ON THE 2016 CBC. THE DEMANDS (DESIGN FORCES) FOR USE WITH THIS OPM SHALL BE BASED ON THE 2016 CBC
- 2. THIS DOCUMENT MAY ONLY BE USED WITH THE EXPRESS WRITTEN CONSENT OF THE MANUFACTURER LISTED ABOVE FOR THE SPECIFIC PROJECT SITE AND INSTALLATION LOCATION. THIS DOCUMENT IS INVALID WITHOUT SUCH CONSENT.
- 3. THIS PREAPPROVAL CONFORMS TO THE 2016 CALIFORNIA BUILDING CODE.
- 4. FORCES PER ASCE 7-10 SECTION 13.3.1, EQUATIONS 13.3-1, 13.3-2 & 13.3-3, WHERE SDS = 2.20, $a_p = 1.0$, $I_p = 1.5$, $R_p = 1.5$, $I_p = 1.5$, I
- 5. THE DETAILS IN THIS PREAPPROVAL MAY BE USED AT ANY LOCATION IN THE STATE OF CALIFORNIA, WHERE SDS IS NOT GREATER THAN 2.20.
- 6. ALL DESIGN FORCES SHOWN ON THE DRAWINGS ARE FACTORED LOADS THAT SHALL BE USED FOR STRENGTH DESIGN.
- 7. SHEET METAL SCREWS SHALL BE TEKS SCREWS BY ITW BUILDEX (ICC ESR-1976).
- 8. THIS PREAPPROVAL COVERS ONLY THE SUPPORTS AND ATTACHMENTS OF THE EQUIPMENT TO THE STRUCTURE.
- 9. RESPONSIBILITIES OF THE STRUCTURAL ENGINEER OF RECORD OF THE BUILDING
 - A. PROVIDE SUPPORTING STRUCTURE REQUIRED TO SUPPORT WEIGHTS AND FORCES SHOWN, IN ADDITION TO ALL OTHER LOADS.
 - B. VERIFY THAT THE INSTALLATION IS IN CONFORMANCE WITH THE 2016 CBC AND WITH THE DETAILS SHOWN IN THIS PREAPPROVAL. VERIFY THAT THE ACTUAL EQUIPMENT'S WEIGHT, CG LOCATION, ANCHOR LOCATIONS, ANCHOR DETAILS AND THE MATERIAL AND GAGE OF THE UNIT WHERE ATTACHMENTS ARE MADE AGREE WITH THE INFORMATION SHOWN ON THE PREAPPROVAL DOCUMENTS.
 - C. VERIFY THAT THE COMBINATION OF SDS & z/h RESULT IN SEISMIC FORCES (Eh , Ev) THAT ARE NOT GREATER THAN THE VALUES ON THE DETAILS.
 - D. DESIGN BACKING BARS, STUDS, ETC. WHICH THE UNITS ARE ATTACHED TO AS NOTED ON THE DRAWINGS.



EQUIPMENT ANCHORAGE & SEISMIC ENGINEERING

www.EquipmentAnchorage.com

DVANCED STERILIZTION PRODUCTS

WALL MOUNTED WATER FILTRATION SYSTEM

DES. J. ROBERSON

11-1517 JOB NO.


5/3/17 DATE

SHEET

SHEETS

SEISMIC SUPPORTS & ATTACHMENTS

WALL MOUNTED



NOTES:

1. FORCES ARE DETERMINED PER 2016 CALIFORNIA BUILDING CODE AND ASCE 7-10.

STRENGTH DESIGN IS USED. (SDS = 2.20, $a_p = 1.0$, $I_p = 1.5$, $R_p = 1.5$, $z/h \le 1$)

HORIZONTAL FORCE (En) = 2.64 Wp VERTICAL FORCE (E_V) = 0.44 W_p

- 2. CENTER OF GRAVITY (C.G.) AND WEIGHT ARE THE GOVERNING PARAMETERS FOR DESIGN, THIS PREAPPROVAL ENCOMPASSES ALL WEIGHTS UP TO THE MAXIMUM WEIGHT SHOWN.
- 3. STRUCTURAL ENGINEER OF RECORD FOR THE BUILDING SHALL PROVIDE SUPPORT STRUCTURE DESIGNED TO SUPPORT WEIGHTS AND FORCES SHOWN IN COMBINATION WITH ALL OTHER LOADS THAT MAY BE PRESENT.
- 4. SEE GENERAL NOTES: SHEET 1.



EASE

EQUIPMENT ANCHORAGE & SEISMIC ENGINEERING

www.EquipmentAnchorage.com

ADVANCED STERILIZTION PRODUCTS

WALL MOUNTED WATER FILTRATION SYSTEM

DES. J. ROBERSON


JOB NO. 11-1517


DATE 5/3/17

SHEET

3

of 5 SHEETS





EQUIPMENT ANCHORAGE & SEISMIC ENGINEERING

www.EquipmentAnchorage.com

DVANCED STERILIZTION PRODUCTS

WALL MOUNTED WATER FILTRATION SYSTEM

DES. J. ROBERSON

11-1517 JOB NO.

5/3/17 DATE


SHEETS

WALL MOUNTED

SEISMIC SUPPORTS & ATTACHMENTS

USE 4- 1/4" PTEK SCREWS TO WALL BACKING (BY STRUCTURAL ENGINEER

AND THE WALL STRUCTURE



WALL PLATE TO WALL CONNECTION

Tu = 125 LB/SCREW (MAX)Vu = 65 LB/SCREW (MAX)

FRONTAELEVATION (WALL PLATE TO WALL CONNECTION)

NOTES:

1. FORCES ARE DETERMINED PER 2016 CALIFORNIA BUILDING CODE AND ASCE 7-10.

STRENGTH DESIGN IS USED. (SDS = 2.20, ap = 1.0, lp = 1.5, Rp = 1.5, $z/h \le 1$)

HORIZONTAL FORCE (En) = 2.64 Wp VERTICAL FORCE (E_V) = 0.44 W_p

- 2. CENTER OF GRAVITY (C.G.) AND WEIGHT ARE THE GOVERNING PARAMETERS FOR DESIGN, THIS PREAPPROVAL ENCOMPASSES ALL WEIGHTS UP TO THE MAXIMUM WEIGHT SHOWN.
- 3. STRUCTURAL ENGINEER OF RECORD FOR THE BUILDING SHALL PROVIDE SUPPORT STRUCTURE DESIGNED TO SUPPORT WEIGHTS AND FORCES SHOWN IN COMBINATION WITH ALL OTHER LOADS THAT MAY BE PRESENT.
- 4. SEE GENERAL NOTES: SHEET 1.



EQUIPMENT ANCHORAGE & SEISMIC ENGINEERING

www.EquipmentAnchorage.com

DVANCED STERILIZTION PRODUCTS

WALL MOUNTED WATER FILTRATION SYSTEM


DES. J. ROBERSON

11-1517 JOB NO.

5/3/17 DATE

SHEET

SHEETS OF



STEEL STUD WALL SECTION (WALL PLATE TO WALL CONNECTION) WOOD STUD WALL SECTION (WALL PLATE TO WALL CONNECTION)

